





Factory reset your Chromebook

1. Sign out of your Chromebook.
2. Press and hold Ctrl + Alt + Shift + r.
3. Select Restart.
4. In the box that appears, select Powerwash




5. Continue.





6. Follow the steps that appear and sign in with your Google Account.
Note: The account you sign in with after you reset your Chromebook will be the owner account.



7. Once you've reset your Chromebook:
 - a. Follow the onscreen instructions to set up your Chromebook
 - b. Check if the problem is fixed